




Leonid Mini Hopper



Installation Guide

Use of Materials Limitations

International Currency Technologies Corporation (ICT) all rights reserved.

All materials contained are the copyrighted property of ICT.

All trademarks, service marks, and trade names are proprietary to ICT.

ICT reserves the right at all times to disclose or to modify any information as ICT deems necessary to satisfy any applicable law, regulation, legal process or governmental request, or to edit, refuse to post or to remove any information or materials, in whole or in part, in ICT's sole discretion.

Contacts

1. Introduction	
1-1. Overview.....	2
1-2. Features.....	2
2. Specifications.....	3
3. Packing List.....	4
4. Dimension.....	5
5. Installation	
5-1. Harness Application.....	6
5-2. I/O Circuit.....	12
5-3. Mini Hopper With CPU Board.....	17
5-3-1. Mini Hopper Setup.....	17
5-3-2. DIP Switch Setting.....	20
5-3-3. Connection.....	22
5-4. Mini Hopper Without CPU Board.....	23
5-4-1. Mini Hopper Setup.....	23
5-4-2. DIP Switch Setting.....	25
5-4-3. Connection.....	25
◆ Adjustment coin dimension.....	26
6. Maintenance.....	28
7. Troubleshooting.....	29
◆ Appendix_ccTalk Information	

1. Introduction

1-1. Overview

Mini hopper is a coin dispensing unit for one denomination. Users can adjust the coin dimension with different coin payout plates and coin adjustment points. The design of Mini Hopper is easy-operated, trouble-free, and high reliability.

1-2. Features

- Dual sensors, double protections.
- Easy maintenance.
- Easy installation.
- Coin size adjustable.
- Advanced coin low level detection.
- Compact design with enormous capacity.

2. Specifications

General

Dispensing Speed	12V DC: 5~6 coins/second 24V DC: 6~8 coins/second
Interface	Pulse, ICT, Hopper, ccTalk *Note: For ccTalk information, please refer to Appendix.
Counting Method	Dual sensors
Installation	Indoor

Electrical

Power Source	MH-12XXX: 12V DC (11.4~12.6V DC) MH-24XXX: 24V DC (22.8~12.6V DC)
Power Consumption	12V DC: Standby: 0.05A, 0.6W Not loaded: 0.75A, 9W Maximum: 2.5A, 30W 24V DC: Standby: 0.05A, 1.2W Not loaded: 0.45A, 10.8W Maximum: 2.5A, 60W
Operation Environment	Operation Temperature: 5°C~50°C Storage Temperature: -15°C~70°C Humidity: 30%~85%RH (no condensation)

Mechanical

Coin Capacity	Approx. 500 coins
Outline Dimension	Refer to page.5
Weight	Approx. 0.8kg

Applicable Coin Size**A TYPE**

(Diameter) 22.5mm~28mm
(Thickness) 1.6mm~2.4mm

B TYPE

(Diameter) 20mm~23mm
(Thickness) 1.6mm~2.2mm

C TYPE

(Diameter) 23mm~30mm
(Thickness) 2.5mm~3.3mm

D TYPE

(Diameter) 23mm~30mm
(Thickness) 1.6mm~2.4mm

F TYPE

(Diameter) 22.5mm~28mm
(Thickness) 1.0mm~1.5mm


3. Packing List**Main**

Mini Hopper

Accessory

Harness: Refer to 5-1

Mini Hopper Installation Guide

4. Dimension

Unit : mm [inch]

Figure 1

5. Installation

5-1. Harness Application

With CPU Board :

Table 1

Interface	Used Voltage	Usage	Harness	Page
ccTalk	12V DC (MH-12XXX)	Power & *Data Comm.	WEL-RHP02	7
		Power & *Data Comm.	WEL-RHP38	8
		Power & *Data Comm.	WEL-R7025	8
Hopper Mode	24V DC (MH-24XXX)	Power & *Data Comm.	WEL-RHP17	9
Pulse Mode		Power & *Data Comm.	WEL-RHP17	9
ICT Mode		*Data Comm.	WEL-R7U06	10

*Data Comm. : Data Communication.

Without CPU Board :

Table 2

Interface	Used Voltage	Usage	Harness	Page
Hopper Mode	12V DC (MH-12XXX)	Power & *Data Comm.	WEL-RHP17	11
	24V DC (MH-24XXX)			

*Data Comm. : Data Communication.

Figure 2




Figure 3




Figure 4




Figure 5





Figure 6



5-2. I/O Circuit

Hopper & Pulse Interface-1.

Figure 7









Figure 8



Hopper & Pulse Interface-2.


Figure 9



-The pulse can be issued before previous coin dispense finished.
 -The minimum timing between pulse and pulse ⇒ 10ms.


ccTalk Interface.

Figure 10



ICT-Protocol Interface.

Figure 11




5-3. Mini Hopper With CPU Board

5-3-1. Mini Hopper Setup:


To setup Mini Hopper, follow the steps below:

(1). For Hopper Mode, Pulse Mode, and ccTalk Mode:


- Setup DIP Switches which are located at the bottom of Mini Hopper according to interface.
(Please refer to (P.20) 5-3-2. DIP Switch Setup.)



- Remove the cover by pressing hooks, and then remove coin box.



- Adjust coin dimensions. (Please refer to P.26 Adjustment Coin Dimension Chart.)



- d. Fill coins in the coin box unit, the coins are higher than empty sensor.




Figure 15

Empty Sensor

- e. Connect the cable to one side of Mini Hopper.
(Please refer to (P.22) 5-3-3. Connection.)

- f. Apply power to Mini Hopper, if LED turns from orange to green, it indicates the machine is completed setup.




Figure 16

- (2). For ICT Mode:

- a. Setup DIP Switches which are located at the bottom of Mini Hopper (as figure 12) according to interface.
(Please refer to (P.20) 5-3-2. DIP Switch Setting)
- b. Connect the cable to one side of Mini Hopper.
(Please refer to (P.22) 5-3-3. Connection.)
- c. Download the software (Mini Hopper Tool Kit) from PC through download box (FP-001).



- ◆ To purchase download box (FP-001) and cables for downloading, please contact ICT.
- ◆ For software (Mini Hopper Tool Kit) downloading, please go on ICT [website: www.ictgroup.com.tw](http://www.ictgroup.com.tw)

5-3-2. DIP Switch Setting:

(1). For MH-XXXXCX

a. ccTalk setup:

ON
OFF

1 2 3 4

Table 3

Function	SW1	SW2	SW3	SW4
Address 3	OFF	OFF		ON
Address 4	ON	OFF		ON
Address 5	OFF	ON		ON
Address 6	ON	ON		ON
Restore Factory Password(0000)			ON	
★ System Password			OFF	

(★) Manufacture setting

b. Hopper mode setup:

ON
OFF

1 2 3 4

Table 4

SW1	SW2	SW3	SW4
N/A	N/A	N/A	OFF

(2). For MH-XXXGX

a. ICT mode setup:

ON
OFF

1 2 3 4

Table 5

SW1	SW2	SW3	SW4
ON	ON	ON	ON

b. Pulse mode setup:

ON
OFF

1 2 3 4

Table 6

Coins/Pulse	SW1	SW2	SW3	SW4
1/1	OFF	OFF	OFF	ON
2/1	ON	OFF	OFF	ON
4/1	OFF	ON	OFF	ON
5/1	ON	ON	OFF	ON
10/1	OFF	OFF	ON	ON
20/1	ON	OFF	ON	ON
50/1	OFF	ON	ON	ON

c. Hopper mode setup:

ON
OFF

1 2 3 4

Table 7

SW1	SW2	SW3	SW4
N/A	N/A	N/A	OFF

!


Please reset Mini Hopper every time after DIP switch setup.

!


Please reset Mini Hopper every time after DIP switch setup.

5-3-3. Connection:

(1) ccTalk Interface Connector




PIN 1- Address select 3
 PIN 2- Address select 2
 PIN 3- Address select 1
 PIN 4- +12V/+24V DC
 PIN 5- +12V/+24V DC




PIN 6- Ground
 PIN 7- Ground
 PIN 8- DATA
 PIN 9- Reserved
 PIN 10- Reset

(2) Download and ICT Interface Connector



PIN 1- Ground
 PIN 2- TXD2
 PIN 3- RXD2
 PIN 4- Program
 PIN 5- /Reset
 PIN 6- VCC
 PIN 7- RXD1
 PIN 8- TXD1

(3) Power and I/O Connector (Hopper Mode or Pulse Mode)



PIN 1- +12V/+24V DC(Power)
 PIN 2- Ground(Power)
 PIN 3- CREDIT RELAY(N.O.)
 PIN 4- CREDIT RELAY(Common)
 PIN 5- PAYOUT_IN


PIN 6- COIN_EMPTY_O
 PIN 7- METER_N.O
 PIN 8- METER_COM
 PIN 9- INHIBIT_N.O
 PIN10- INHIBIT_COM

5-4. Mini Hopper Without CPU Board


5-4-1. Mini Hopper Setup:

To setup Mini Hopper, follow the steps below:


- a. Setup DIP Switches which are located at the bottom of Mini Hopper according to interface.
 (Please refer to (P.25) 5-4-2. DIP Switch Setup.)



- b. Remove the cover by pressing hooks, and then remove coin box.



- c. Adjust coin dimensions. (Please refer to (P.26) Adjustment Coin Dimension Chart.)



- d. Fill coins in the coin box unit, the coins are higher than empty sensors.




Figure 21

Empty Sensor

- e. Connect the cable to one side of Mini Hopper.
(Please refer to (P.25) 5-4-3. Connection.)

- f. Apply power to Mini Hopper, if LED turns from orange to green, it indicates the machine is completed setup.





Figure 22

5-4-2. DIP Switch Setting:

- (1). For MH-XXXHX

- a. Credit output function setup:




SW1
Normal Open
Normal Close

Table 8

5-4-3. Connection:

- (1). Power and I/O Connector
(Hopper Mode)



TMT2*5

- PIN 1- +12V/+24VDC (Power)
- PIN 2- Ground (Power)
- PIN 3- Credit Relay (N.O.)
- PIN 4- Credit Relay (Common)
- PIN 5- TRIGGER_IN-
- PIN 6- Coin_Empty_Output
(Normal Open Active Low)
- PIN 7- TRIGGER_IN+
- PIN 8- N/A
- PIN 9- N/A
- PIN 10- N/A




Figure 23

◆ Adjustment coin dimension :

Table 9
















Coin Payout Plate	Coin Payout Adjustment	Diameter	22.5mm ≤ 28mm
A	C1607A	thickness	1.6mm ≤ 2.4mm
 Part number A25140-R		Diameter	25.5mm ≤ 28mm
		thickness	1.6mm ≤ 2.4mm
		Diameter	22.5mm ≤ 25.5mm
		thickness	1.6mm ≤ 2.4mm
Coin Payout Plate	Coin Payout Adjustment	Diameter	20mm ≤ 23mm
B	C1607A	thickness	1.6mm ≤ 2.2mm
 Part number A25920-R		Diameter	22.5mm ≤ 23mm
		thickness	1.6mm ≤ 2.2mm
		Diameter	20mm ≤ 22.5mm
		thickness	1.6mm ≤ 2.2mm
Coin Payout Plate	Coin Payout Adjustment	Diameter	23mm ≤ 30mm
C	C1607A	thickness	2.5mm ≤ 3.3mm
 Part number A26740-R		Diameter	25.5mm ≤ 28mm
		thickness	2.5mm ≤ 3.3mm
		Diameter	23mm ≤ 25.5mm
		thickness	2.5mm ≤ 3.3mm
		Diameter	28mm ≤ 30mm
		thickness	2.5mm ≤ 3.3mm

Table 10


Coin Payout Plate	Coin Payout Adjustment	Diameter	23mm ≤ 30mm
D	C1607A	thickness	1.6mm ≤ 2.4mm
 Part number A28730-R		Diameter	25.5mm ≤ 28mm
		thickness	1.6mm ≤ 2.4mm
		Diameter	23mm ≤ 25.5mm
		thickness	1.6mm ≤ 2.4mm
Coin Payout Plate	Coin Payout Adjustment	Diameter	22.5mm ≤ 28mm
F	C1607A	thickness	1.0mm ≤ 1.5mm
 Part number A31150-R		Diameter	25.5mm ≤ 28mm
		thickness	1.0mm ≤ 1.5mm
		Diameter	22.5mm ≤ 25.5mm
		thickness	1.0mm ≤ 1.5mm

6. Maintenance

To make sure the Mini Hopper always works smoothly, we suggest you clean the internal parts of Mini Hopper regularly.

 Please make sure Mini Hopper turns OFF before cleaning.

- To clean the internal parts:
- 1. Remove the coin box.
 - 2. Use a dry, soft cloth, or brush to clean internal parts and coin path.
 - 3. Use a dry, soft cloth, or towel to clean the coin box.







Maintenance Notice
(Any improper maintenance will result invalid warranty.)

Recommended	Mild, non-abrasive, soap water.
DO NOT USE	Organic solvent , Alcohol, Volatile liquid.

7. Troubleshooting

Table 11


Flashes	Status	Corrective actions
1	1. Incorrect voltage 2. Coin jammed 3. Motor problem	1. Make sure the voltage is applied to Mini Hopper. 2. Clockwise turn the wheel which is in the back of Mini Hopper to remove the jammed coin and check the shaft-block.  Figure 25
2	Insufficient coins	Refill coins or Rester hopper
3	Double count detect	1. Re-adjust coin size and shaft. 2. Check the control signal refer to figure 8. (After last credit signal output then PAYOUT_IN signal must stop in 12ms other wise may cause coin leak out.)
5	Prism sensor error	Inspect for foreign objects on prism sensor or jammed coins. (as figure 26)
6	Shaft sensor error	


Figure 26

 If the errors can not be solved after corrective actions or happen again, please contact ICT for technical support.

◆ ccTalk Information

- Manufacturer ID: ICT
- Equipment Category ID: Payout
- Product Code: MH-125/ 245
- Build Code: Standard
- Serial Number: Default as 1 2 3 4 5 6 7 8
- Software Revision: Software Revision label locates in the bottom of Mini Hopper.



ict Taiwan

International Currency Technologies Corporation

Ji-Hong Building, No 24, Alley 38, Lane 91, Nei-hu Rd., Sec. 1, Taipei, Taiwan, R.O.C.

Tel: 886-2-2797-1238 · Fax: 886-2-2797-1634

sales@ictgroup.com.tw (For Sales)

rma@ictgroup.com.tw (For Customer Service)

Website: www.ictgroup.com.tw



Please contact ICT for more information.