

Hardware Setup

2.1. Parts of the Terminal

Contactless Card Landing Zone

1. LCD Display
2. Smart Card Reader
3. Magnetic Stripe Reader
4. Front Camera
5. Product Label
6. MDB Port
7. Ethernet Port
8. GSM Micro SIM Card Slots
9. SAM Card Slots
10. USB Type A Slot (5Vdc, 0.5A max.)
11. USB Type C Slot (5Vdc, 0.5A max.) **Note:** USB Type A Slot + USB Type C Slot: 0.5A max.
12. Antenna Slot
13. Aiming LED
14. Barcode scanner
15. Illumination
16. peak
17. microphone

2.2. Insert SAM Card Insert SAM card into desire slot. SAM 1: Cut corner is on the upper

left side. SAM 2: Cut corner is on the bottom left side. **2.3. Insert GSM Micro SIM**

Card Insert GSM Micro SIM card into desire slot. SIM 1: Cut corner is on the upper left


side. SIM 2: Cut corner is on the upper right side.

Front



S1U2

Rear



S1U2

Bottom




S1U2

Left side




Right side





S1U2



S1U2